

## V3 DC Input Jack Split Pin Adjustment

The DC Input Jack on the V3 has a split center pin that can compress and give intermittent operation. Use a small jewelers screwdriver to *gently* separate the center pin so it looks like the “GOOD” picture (be careful not to spread too much). Some people have reported good results using a small piece of rubber band to keep the pin spread.

